



# HEADLIGHT RESTORE KIT

## DIRECTIONS & APPLICATION INFORMATION/TDS

HEADLIGHT  
**RESTORE**  
KIT

**The KBS Headlight Restore Kit is designed to restore headlight lenses that are losing clear visibility. This increases the visibility capacity of fogged, yellowed, cloudy or hazy dull looking headlights by improving their performance. Contains KBS Klean, DiamondFinish Clear, Scuff Pad, Brush, and Gloves.**

ALWAYS WEAR PROTECTIVE GLOVES AND SAFETY GLASSES. ALWAYS WORK IN A WELL-VENTILATED AREA. Please heed all warning and caution notices on all KBS products. For Professional Use Only.

**1. ASSESS CURRENT HEADLIGHT CONDITION:** Although our KBS Headlight Restore Kit has been said to “perform miracles”, the condition of some lenses are beyond restoration and need to be replaced. Please evaluate your headlight lenses objectively before proceeding.

**2. KLEAN & SCUFF:** In a proper container, mix 1 part KBS Klean with 10 parts hot water. Wearing gloves provided, dip scuff pad in Klean solution and Klean & scuff the entire headlight lens surface to remove any bugs, tar, wax, and/or road contaminants. NOTE: Be careful not to scuff any surrounding painted or chromed surfaces. Rinse thoroughly with clean water. Repeat Klean as necessary. Using a clean & dry towel/cloth, dry lens surface to remove standing water to eliminate spotting. Allow lenses to air dry thoroughly.

**3. APPLY DIAMONDFINISH CLEAR:** NOTE: Do not apply in direct sunlight. Open can and stir contents thoroughly. DO NOT SHAKE. Using supplied brush(es), working from top to bottom & side to side, apply a liberal coat of DiamondFinish clear brushing mainly in one direction. Do not over brush the coating. Avoid applying too heavy to avoid runs & drips. Once coated, allow DiamondFinish Clear to dry (typically 1-2 hrs to touch). Allow at least overnight curing before putting lenses back into service. One coat is normally sufficient for lasting protection. A 2nd coat may be applied any time after 48 hrs.

**4. CLEAN UP:** Use KBS #1 Thinner or lacquer thinner for immediate clean up. IMPORTANT: Remember DiamondFinish Clear must be cleaned up before it dries. It cannot be removed by any solvent once cured. Always wear protective gloves to avoid skin contact. If skin contact accidentally occurs, immediately remove with #1 Thinner or lacquer thinner followed by soap and water.

Consult SDS for additional information.

DO NOT TAKE INTERNALLY.  
HARMFUL IF SWALLOWED.

*Information contained herein is to our knowledge true and accurate, but all recommendations or suggestions are made without guarantee. Since application lies outside our control, we cannot accept any liability for the results. User shall determine the suitability of the product for its intended use, and user assumes all risk and liability whatsoever in connection therewith.*

### KBS SUPPORT FORUM

[SUCCESS.KBS-COATINGS.COM](http://SUCCESS.KBS-COATINGS.COM)

### KBS FAQ's & SUPPORT TICKETS

[SUPPORTDESK.KBS-COATINGS.COM](http://SUPPORTDESK.KBS-COATINGS.COM)

### COMPLETE HOW-TO's

[KBS-COATINGS.COM](http://KBS-COATINGS.COM)

### KBS ONLINE INSTRUCTIONAL VIDEOS

VIEW 3-STEP SYSTEM APPLICATION VIDEOS  
AVAILABLE ON [KBS-COATINGS.COM](http://KBS-COATINGS.COM)